


MANUAL TUBE PULLER



Ideally suitable for small maintenance job. Manual tube puller allows easy removal off stubs and tubes. Can be use with impact wrench in combination with drive socket.

SPECIFICATIONS

O. D.		BWG	Tube Size Wall Thickness		I. D.		Tube Puller Model Number	Spare Spear Model Number
mm	inch		mm	inch	mm	inch		
6.35	1/4	18	1.24	0.49	3.86	.152	MTP-25-18	MPS-25-18
9.52	3/8	16	1.65	0.65	6.22	.245	MTP-38-16	MPS-38-16
9.52	3/8	18	1.24	0.49	7.04	.277	MTP-38-18	MPS-38-18
9.52	3/8	20	0.88	0.35	7.75	.305	MTP-38-20	MPS-38-20
12.70	1/2	14	2.11	0.83	8.48	.334	MTP-50-14	MPS-50-14
12.70	1/2	16	1.65	0.65	9.40	.370	MTP-50-16	MPS-50-16
12.70	1/2	18	1.24	0.49	10.21	.402	MTP-50-18	MPS-50-18
12.70	1/2	20	0.88	0.35	10.92	.430	MTP-50-20	MPS-50-20
15.88	5/8	14	2.10	0.83	11.66	.459	MTP-63-14	MPS-63-14
15.88	5/8	16	1.65	0.65	12.57	.495	MTP-63-16	MPS-63-16
15.88	5/8	18	1.24	0.49	13.39	.527	MTP-63-18	MPS-63-18
15.88	5/8	20	0.88	0.35	14.10	.555	MTP-63-20	MPS-63-20
19.05	3/4	14	2.10	0.83	14.86	.585	MTP-75-14	MPS-75-14
19.05	3/4	16	1.65	0.65	15.75	.620	MTP-75-16	MPS-75-16
19.05	3/4	18	1.24	0.49	16.56	.652	MTP-75-18	MPS-75-18
19.05	3/4	20	0.88	0.35	17.27	.680	MTP-75-20	MPS-75-20
22.22	7/8	14	2.10	0.83	18.01	.709	MTP-87-14	MPS-87-14
22.22	7/8	16	1.65	0.65	18.92	.745	MTP-87-16	MPS-87-16
22.22	7/8	18	1.24	0.49	19.74	.777	MTP-87-18	MPS-87-18
22.22	7/8	20	0.88	0.35	20.45	.805	MTP-87-20	MPS-87-20
25.40	1	14	2.10	0.83	21.18	.834	MTP-100-14	MPS-100-14
25.40	1	16	1.65	0.65	22.10	.870	MTP-100-16	MPS-100-16
25.40	1	18	1.24	0.49	22.91	.902	MTP-100-18	MPS-100-18
25.40	1	20	0.88	0.35	23.62	.930	MTP-100-20	MPS-100-20